

While fixing doors and windows, keep the following points in mind.

01



Assay different materials like wood, metal, PVC or concrete for the windows.

02

While constructing the walls, the frames are fixed at their specified place.



03



Plum bob is used for correct alignment of the frames.

04

Position is fixed with the help of holdfast in frame and wall; these are Z shaped.



05



For doors 3 holdfasts are used and two for the windows and afterwards those are filled with the concrete.

04

Fill the gap at the sides and below with the concrete.



For more information on home-building, click here.